

SPEND ONLY 3 HRS
WITH SQUARE FOOT™



SQUARE FOOT™

Sound Footings, LLC

37 Talcott Road, PO Box 818, Williston, VT 05495

Tel: 802-764-2323, Fax: 802-764-5605

www.sqfoot.com



**BE SMART
BE SQUARE**

SPEND 3 DAYS OR
WITH THIS TRADITIONAL METHOD





IT'S EASY AS...

1.



Cut off excess plastic at wedges to construction tube size and saw construction tube to desired length.

2.



Attach construction tube to Square Foot™ with a minimum of four, 1" (2.5cm) screws.

3.



Place Square Foot™ in excavated hole and backfill. Ensure tube remains level/plumbed.

SQUARE. ORANGE. SMART.

SF 22



SF 28



SF 32



Our patented code approved square design is not only fast & easy, Square Foot™ also creates a structurally stronger footing by increasing stability, increasing capacity, resisting uplift, accomodating rebar, allowing a continuous concrete pour. The Square Foot™ product line lifts any 8" through 18" construction tube with its unique wedge system.

TUBEBASE®; ICBO CODE APPROVED, IS NOW CALLED SQUARE FOOT™

